



Gamma Silicone Cold Shrink Install Instructions

1) Slide the Cold Shrink sleeve over the connector and cable. The loose end of the Plastic spiral must be on the bottom (cable) end.



2) Install the connector on the remote radio unit or antenna.



3) Verify the exterior of the connector and cable is clean and dry. Then slide the Cold Shrink sleeve over the connection until the spiral touches the connector receptacle. Pull the loose end on the bottom side while pressing the top side against the connector.



4) Ensure the Cold Shrink Boot still touches the receptacle of the connector, while pulling on the loose end. If necessary, press the cold shrink sleeve lightly against the receptacle.



5) Keep pulling the plastic spiral on the bottom side until the plastic spiral is completely removed from the cold shrink.



Property of Gamma Electronics Inc.
2818 Metropolitan Place, Suite A
Pomona, CA 91767
www.gammaelectronics.net